

Toyota Corolla (EE 90) 88-91 H/B

CORNER LAMP (E) LEFT

CORNER LAMP (E) RIGHT

COVER ENGINE PLASTIC LEFT

DOOR HANDLE INSIDE FRONT LEFT

DOOR HANDLE INSIDE FRONT RIGHT

DOOR HANDLE OUTSIDE FRONT LEFT

DOOR HANDLE OUTSIDE FRONT RIGHT

DOOR HANDLE OUTSIDE REAR LEFT

DOOR HANDLE OUTSIDE REAR RIGHT

DOOR MIRROR ADJUSTABLE LEFT

DOOR MIRROR ADJUSTABLE RIGHT

ENGINE COVER PLASTIC RIGHT

FR.PANEL LOCK

FRONT BUMPER

FRONT BUMPER STAY LEFT

FRONT BUMPER STAY RIGHT

FRONT FENDER LEFT

FRONT FENDER RIGHT

FRONT LAMP LEFT

FRONT LAMP RIGHT

---

FRONT PANEL

GRILLE

HEAD LAMP (E) LEFT

HEAD LAMP (E) RIGHT

HOOD

HOOD HINGE LEFT

HOOD HINGE RIGHT

HOOD LOCK

INNER PLASTIC FENDER LEFT

INNER PLASTIC FENDER RIGHT

RAD 1,3-1,6CC (57\*32,5)

RAD 1,3-1,6CC (66,8\*32,5)

RADIATOR A/C (64.7\*28.8)

TAIL LAMP LEFT

VENTILATOR BASE

VENTILATOR RAD.COMPLETE PETROL

WINDOW REGUL.FR.ELECTR.3D LEFT

WINDOW REGUL.FR.ELECTR.3D RIGHT